

MAINTENANCE SCHEDULE

<p>CHECK WITH EACH FUEL STOP</p> <ul style="list-style-type: none"> () Check crankcase oil level () Check radiator water level () Check water pump packing () Visual inspection of engine <p>CHECK MONTHLY</p> <ul style="list-style-type: none"> () Check radiator water level () Check water pump for leaks and end play () Check water pump packing () Inspect fan for cracks () Check carburetor and fuel lines for leaks () Check battery water level () Check tire pressure (34lbs) () Check tires for breaks, cracks, and abnormal wear () Visually inspect engine <p>EVERY 500 MILES</p> <ul style="list-style-type: none"> () Lubricate in accordance with 500 mile Lubrication chart () Change crankcase oil () Tighten accessory mountings (windwings) () Inspect radiator hoses for cracks/leaks () Check fan belt adjustment () Check wiper blade rubber () Check generator charging rate, adjust as required () Check carburetor and fuel lines for leaks 	<p>EVERY 1,000 MILES</p> <ul style="list-style-type: none"> () Perform 500 mile checks () Test front wheel bearings for looseness () Oil generator bushings at each end of generator () Tighten spring U-bolts, front and rear () Tighten all wheel lug nuts (64 ft lbs) () Test all lights () Inspect all cotter pins () Clean Light Switch and wiring harness disc () Lubricate door hinges, striker plate, dovetails () Inspect entire fuel system for leaks () Inspect Exhaust system for leaks () Check manifold to exhaust clamp for tightness and seal () Check steering wheel free play (2 in. max) () Check specific gravity of battery fluid, charge if needed () Check for tight electrical connections at all harness connections. () Check for tight coil connections () Check for tight connections at ammeter and terminal box () Check distributor point gap (.018 - .022) () Clean battery posts and clamps, tighten battery ground connection () Clean horn commutator () Drain fuel sediment bowl () Replace fuel filter if used 	<ul style="list-style-type: none"> () Check clutch pedal for 1" free play. Adjust if necessary () Check tail light lens mounting screws <p>EVERY 2,000 MILES</p> <ul style="list-style-type: none"> () Perform all 1,000 mile checks () Lubricate in accordance with 2,000 mile Lubrication Chart () Inspect starter commutator and brushes () Examine tires for wear, cracks and damage () Adjust Service Brakes () Inspect front leaf spring for sagging and cracks () Repack top end of shock links () Tighten differential banjo bolts (35 ft lbs) <p>EVERY 5,000 MILES</p> <ul style="list-style-type: none"> () Perform all 2,000 mile checks () Test engine compression () Tighten rear wheel axle nuts (100 ft lbs) () Rotate tires () Lubricate in accordance with 5,000 mile Lubrication Chart () Flush cooling system () Lubricate speedometer cable <p>EVERY 10,000 MILES</p> <ul style="list-style-type: none"> () Perform all 5,000 mile checks () Pull all brake drums, inspect brake linings, drum, and springs () Polish headlight reflectors
--	--	---